



MAKE 2 OF THESE FOR EACH UNIT.
ASSEMBLE WITH 2 1/4" x 2" CARRIAGE BOLTS WITH FLAT WASHERS AND WING NUTS.

THREAD 2 PIECES OF 1/4" NYLON CORD THROUGH HOLES IN PLYWOOD. ADJUST LENGTH OF CORD TO SET ANGLE BETWEEN PANELS

